

TABLE OF CONTENTS



Chapter 1 - Introduction

Introduction	1–2
Purpose of this Manual.....	1–2
Other Reference Materials	1–2
Who Should Read this Manual	1–2
Technical Support	1–2
Conventions Used.....	1–3
Key Topics for Each Chapter	1–3
Ethernet Remote Master (ERM).....	1–4
Ethernet Remote Slaves	1–4
Configuring the Ethernet Remote I/O Network	1–5
Running the Ethernet Remote I/O Network.....	1–5
ERM / ECOM Systems	1–6
Dedicated ERM Network	1–6
How the PLC CPU Updates Remote I/O Points	1–7
Frequently Asked Questions.....	1–8

Chapter 2 - ERM / Slave Network Addressing Modes

ERM/Remote Slave Network Identifiers	2–2
ERM / Slave Configuration Tools	2–2
ERM / Slave Module ID	2–3
IP Address 2–4	
Ethernet Address	2–4
Using Multiple Network Identifiers	2–4

Table of Contents

Chapter 3 - Installation and Network Layout

Inserting the ERM Module in the I/O Base	3-2
DL205/Do-more! Slot Choices.....	3-2
H2-ERM (100, -F) Module Installation.....	3-2
DL405 Slot Choices.....	3-3
H4-ERM(100, -F) Module Installation	3-4
Which Modules are Supported in the Ethernet Slaves	3-4
ERM Network Layouts	3-5
Configuring the Ethernet Remote I/O Network	3-5
Running the Ethernet Remote I/O Network.....	3-5
ERM / ECOM Systems	3-6
Network Cabling.....	3-7
ERM Supports Three Standards	3-7
10/100BaseT Networks	3-7
10/100BaseT	3-8
UTP Cable	3-8
10BaseFL.....	3-8
Fiber Optic Cable	3-8
Fiber Optic Module ST Connector.....	3-8
Maximum Cable Length	3-9

Chapter 4 - Configuring the ERM And Slave Modules with ERM Workbench

ERM Workbench Software	4-2
Launching ERM Workbench	4-2
Adding IPX Network Protocol Support on PCs with Windows XP (32 bit only) or Earlier Operating Systems.....	4-3
Running ERM Workbench PLC Wizard	4-4
Step 1: Choosing the ERM Network Configuration	4-4
Step 2: Connecting the ERM Workbench PC to the ERM Network.....	4-4
Establishing Communication with the ERM	4-5
Step 3: Select and Configure the Slaves	4-5
Step 4: Map I/O to PLC Memory	4-6
Step 5: Download Configuration to ERM	4-6
ERM Workbench Main Configuration Window	4-7

Running ERM Workbench	4-8
Connecting the ERM Workbench PC to the Network Modules.....	4-8
Configure the ERM	4-9
Configuring the ERM.....	4-9
Selecting PLC as Interface	4-9
PLC Map	4-10
Advanced ERM Configuration	4-10
Select the Slaves	4-11
Selecting the Slaves.....	4-11
Configure the Slaves.....	4-12
Setting the Slave's Parameters.....	4-12
Write Configuration to ERM	4-14
Analog I/O Data Registers.....	4-15
Analog I/O Data Registers	4-15
Reserved PLC Memory for ERM	4-16
ERM Status Word / Reset Slave Code	4-16
Saving ERM Configuration to Disk.....	4-17
Clear ERM Configuration.....	4-17
Printing/Exporting the ERM Configuration.....	4-17

Chapter 5 - Using NetEdit

Using NetEdit.....	5-2
The NetEdit Window.....	5-2
Ethernet Communication Protocol	5-2
Adding IPX Network Protocol Support on PCs with Windows XP (32 bit only) or Earlier Operating Systems.....	5-3
Ethernet Address	5-3
Module ID / IP Address / Name / Description	5-4
Module Information	5-4
Using NetEdit to Configure the EBC Base	5-5
EBC Settings Tab.....	5-5
General Settings.....	5-6
Serial Port.....	5-6

Table of Contents

I/O Base	5-6
Show Base Contents.....	5-7
Update Firmware	5-8
Update Booter.....	5-8
Restore Factory Defaults	5-8

Chapter 6 - Maintenance and Troubleshooting

Isolating a Communication Problem	6-2
Diagnostic Tools and Techniques	6-2
Troubleshooting Chart	6-2
ERM Module Diagnostic LEDs	6-4
Slave Module Diagnostic LEDs	6-4
EBC LEDs.....	6-4
Error Indicator	6-4
Using ERM Workbench for Troubleshooting.....	6-5
Read from ERM	6-5
Reserved PLC Memory for ERM	6-6
Detailed ERM Statistics	6-6
Select Slaves Window.....	6-7
Using NetEdit for Troubleshooting.....	6-8
Select a Module	6-8
Module Information	6-8
Change Protocol	6-9
Replacing the ERM / Slave Module.....	6-9
Diagnosing Network Cable Problems.....	6-10

Appendix A - General Specifications

General Specifications	A-2
Specifications	A-2
Ethernet Standards.....	A-4

Appendix B - ERM/Slave Diagnostics and Error Codes

ERM Diagnostics	B-2
ERM Status Word / Resetting the Slave	B-2
<i>Direct</i> LOGIC Example.....	B-3
Do-more! Example	B-3
ERM Status Word Error Codes	B-4
Reading ERM Statistics	B-5
Reading ERM Statistics using Ladder Logic with <i>Direct</i> LOGIC	B-5
Reading ERM Statistics using Ladder Logic with Do-more!	B-6
Reading Error Codes from Slaves.....	B-7
Reading Error Codes from Slaves with <i>Direct</i> LOGIC	B-7
Reading Error Codes from Slaves with Do-more!.....	B-9
Slave Diagnostic Word Memory	B-10
Current / Last State Slave Error Codes	B-12
Extended Slave Error Codes	B-13

Appendix C - ERM and ERM Workbench Default Settings

ERM and ERM Workbench Factory Default Settings.....	C-2
--	------------

Appendix D - Mapping ERM Slave I/O in a Think & Do WinPLC Slave System

Mapping ERM Slave I/O Points.....	D-2
Launching Connectivity Center Tool	D-2
Connecting to the WinPLC Base I/O	D-2
Connecting to the ERM Slave I/O.....	D-3
Mapping I/O Points to Data Items	D-3

Table of Contents

Appendix E - Configuring Terminator I/O Analog Output Modules

Analog Output Module Control Byte	E-2
DirectLOGIC.....	E-2
Do-more	E-2
<i>Direct</i> SOFT	E-3
Do-more Designer.....	E-4

Appendix F - H2-EBC(100) Analog Module Addressing

H2-EBC(100) Analog Module Addressing - H2/4-ERM(100)	F-2
--	-----