

USER MANUAL TABLE OF CONTENTS



CONTENTS OF SURESERVO USER MANUAL

Warnings and Trademarks	W-1
~ WARNING ~	W-1
Trademarks	W-1
~ AVERTISSEMENT ~	W-2
Marques de commerce	W-2
Warnings	W-3
User Manual Revision History	H-1
User Manual Table of Contents	TOC-1
Chapter 1: Getting Starting	1-1
Manual Overview	1-2
Overview of This Publication	1-2
Who Should Read This Manual	1-2
Supplemental Publications	1-2
Technical Support	1-2
Special Symbols	1-2
SureServo® AC Servo Systems Introduction	1-3
SureServo Basic Overview	1-3
Unpacking Your New SureServo	1-4
Nameplate Information	1-4
Model Explanation	1-4
Identification and Labeling: SureServo® AC Servo Drive	1-5
Drive and Motor Combinations	1-5
SureServo® AC Servo Drive Control Modes	1-6
SureServo® AC Servo System Specifications	1-7
Drive Specifications	1-7
Motor Specifications	1-9
Motor Velocity-Torque Curves	1-10
Motor Overload Characteristics	1-11
Quick Start for SureServo® Drives	1-12
Spin the Motor	1-12
Position Mode Quick Start (Pt & Pr)	1-14
Velocity Mode Quick Start (V & Vz)	1-17
Torque Mode Quick Start (T & Tz)	1-18
Tuning Quick Start for SureServo® Drives	1-20

Chapter 2: Installation and Wiring	2-1
Storage Conditions	2-2
Installation	2-2
Servo Drive Mounting	2-2
Servo Drive Minimum Clearances and Air Flow.	2-3
Servo Motor Mounting	2-3
Dimensions	2-4
Servo Drive Dimensions	2-4
Servo Motor Dimensions	2-6
Accessory I/O Terminal Module Dimensions	2-7
Circuit Connection Warnings.	2-8
Danger!.	2-8
Wiring Notes: PLEASE READ PRIOR TO INSTALLATION.	2-8
Servo Drive Terminals.	2-9
Drive Power Terminals.	2-9
CN1 – Drive Input/Output Terminal	2-10
CN2 – Drive Encoder Terminal	2-14
CN3 – Drive Serial Communication Terminal	2-15
Servo Motor Terminal Connections	2-16
Motor Power Connections	2-16
Motor Encoder Connections	2-17
Wiring Diagrams	2-18
Connecting to Peripheral Devices	2-18
Power Wiring Connections	2-19
Wiring for Position (Pr & Pt) Control Modes	2-20
Wiring for Velocity and Torque Control Modes.	2-21
CN1 Input/Output Wiring Diagrams.	2-22
CN2 Encoder Wiring Diagram	2-24
CN3 Serial Communication Wiring Diagram	2-24
Cables and Terminal Connectors.	2-25
Drive, Motor, and Cable Combinations	2-25
Drive Terminal Connection Module & Cables.	2-26
Serial Cables for Connection to CN3	2-27
Servo Drive Circuit Protection	2-27

Chapter 3: Keypad and Display Operation	3-1
<i>Digital Keypad</i>	3-2
<i>Display Flowchart</i>	3-3
<i>Display Messages</i>	3-4
<i>Parameter Setting Value Change Messages</i>	3-4
<i>Abort Parameter Setting Value Change Message</i>	3-4
<i>Fault Message Display</i>	3-4
<i>Polarity Display of Parameter Setting Values</i>	3-4
<i>Monitor Mode Function Display</i>	3-5
<i>Polarity Display of Monitor Values</i>	3-5
Servo Drive General Operation	3-6
<i>Display Fault History</i>	3-6
<i>JOG Function</i>	3-6
<i>Teach Position Function</i>	3-7
<i>DO Force Output Function</i>	3-8
<i>Display Digital Input Status</i>	3-9
<i>Display Digital Output Status</i>	3-9
 Chapter 4: Servo Drive Parameters	 4-1
<i>Parameter Overview and Note Symbols</i>	4-2
<i>Parameter Groups</i>	4-2
<i>Reset Parameter Defaults</i>	4-2
<i>Parameter Firmware Versions</i>	4-2
<i>Parameter Summary</i>	4-3
<i>Parameter Summary Listings</i>	4-3
<i>Detailed Parameter Listings</i>	4-10
<i>Sample Parameter Listing</i>	4-10
<i>Monitor Parameters</i>	4-11
<i>Basic Parameters</i>	4-16
<i>Extended Parameters</i>	4-35
<i>Communication Parameters</i>	4-52
<i>Diagnostic Parameters</i>	4-55

Chapter 5: Control Modes of Operation and Tuning	5-1a
Control Modes of Operation.	2
How to Change Control Modes	2
Position Control Modes	3
Structure of Position Control Modes	3
Electronic Gear Ratio	4
Position Command Low-pass Filter	4
Position Loop Gain Adjustment	5
Command Source of Pt Position Control Mode	6
Command Source of Pr Position Control Mode	6
Timing Chart of Pr Position Control Mode	7
Teach Position Function for Pr Absolute Position Control	8
S-curve Filter for Pr Position Control	8
Parameters for Absolute and Incremental Pr Control (P1-33 = 0,1)	9
Parameters for Index Mode Pr Control (P1-33 = 2,3,4)	11
Parameters for Absolute and Incremental Auto Pr Control (P1-33 = 5,6)	20
Velocity Control Mode	24
Command Source of Velocity Control Mode	24
Structure of Velocity Control Mode	25
Smoothing Strategy of Velocity Control Mode	26
Analog Velocity Input Scaling	27
Timing Chart of Velocity Control Mode	27
Velocity Loop Gain Adjustment	27
Resonance Suppression	28
Torque Control Mode.	30
Command Source of Torque Control Mode	30
Structure of Torque Control Mode.	31
Smoothing Strategy of Torque Control Mode	31
Analog Torque Input Scaling	32
Timing Chart of Torque Control Mode	32
Dual Control Modes Selection.	33
Position / Velocity Control Mode Selection.	33
Position / Torque Control Mode Selection	34
Velocity / Torque Control Mode Selection	35
Limits.	36
Velocity Limit	36
Torque Limit	36
Regenerative Resistor.	37
Built-in Regenerative Resistor	37
External Regenerative Resistor.	37
Electromagnetic Brake	39
Timing charts of control circuit power and main circuit power:.	40
Tuning Modes Overview	41
Purpose of Tuning; Why and When it is Necessary	41
SureServo™ Tuning Modes Available	42
Tuning Modes and Their Relevant Parameters	43
Monitoring System Performance	43
Tuning Modes Details	44
Auto-Tuning Modes	44
Using Auto-Tune PDFF Mode	46
Using Easy-Tune Mode	47
Using Manual Tuning Mode	49
Manual Tuning Mode Details	51

Chapter 6: Modbus Communications	6-1
<i>SureServo™ Communication Parameters</i>	6-2
<i>SureServo™ Parameter Memory Addresses</i>	6-3
<i>Connecting to DirectLogic PLCs</i>	6-7
<i>Step 1: Modbus RTU Master PLCs</i>	6-7
<i>Step 2: Make the Connections</i>	6-7
<i>Step 3: Confirm/Set Servo Communication Parameters</i>	6-8
<i>Step 4: Configure the DirectLOGIC CPU Port 2</i>	6-9
<i>SureServo™ / DirectLOGIC PLC Control Example</i>	6-11
<i>DirectLOGIC Ladder Logic Programming Example</i>	6-13
<i>Communicating with Third-party Devices</i>	6-20
<i>Common Modbus RTU Masters</i>	6-20
<i>Modbus Protocol Modes</i>	6-20
<i>Modbus ASCII and RTU Data Format</i>	6-21
<i>Communication Protocol</i>	6-22
 Chapter 7: Maintenance and Troubleshooting	 7-1
<i>Maintenance and Inspection</i>	7-2
<i>Basic Inspection</i>	7-2
<i>Maintenance</i>	7-3
<i>Expected Life of Replacement Components</i>	7-3
<i>DC BUS Filter Capacitor</i>	7-3
<i>Precharge Relay</i>	7-3
<i>Cooling fan (SVA-2100 and SVA-2300 Models Only)</i>	7-3
<i>Troubleshooting</i>	7-4
<i>Fault & Warning Message Table</i>	7-4
<i>Fault Message Potential Causes and Corrective Actions</i>	7-5
<i>Warning Message Potential Causes and Corrective Actions</i>	7-7
<i>Clearing Faults</i>	7-8

Appendix A: Selecting the SureServo System	A-1
<i>Selecting the SureServo® Servo System</i>	A-2
<i>The Selection Procedure</i>	A-2
<i>How many pulses from the PLC to make the move?</i>	A-2
<i>What is the positioning resolution of the load?</i>	A-3
<i>What is the indexing speed to accomplish the move time?</i>	A-3
<i>Calculating the Required Torque.</i>	A-4
<i>Leadscrew – Example Calculations.</i>	A-8
<i>Step 1 – Define the Actuator and Motion Requirements.</i>	A-8
<i>Step 2 – Determine the Positioning Resolution of the Load.</i>	A-8
<i>Step 3 – Determine the Motion Profile</i>	A-9
<i>Step 4 – Determine the Required Motor Torque</i>	A-9
<i>Step 5 – Select and Confirm the Servo Motor and Driver System.</i>	A-10
<i>Belt Drive – Example Calculations</i>	A-11
<i>Step 1 – Define the Actuator and Motion Requirements.</i>	A-11
<i>Step 2 – Determine the Positioning Resolution of the Load.</i>	A-11
<i>Step 3 – Determine the Motion Profile</i>	A-12
<i>Step 4 – Determine the Required Motor Torque</i>	A-12
<i>Step 5 – Select and Confirm the Servo Motor and Driver System.</i>	A-13
<i>Index Table – Example Calculations</i>	A-14
<i>Step 1 – Define the Actuator and Motion Requirements.</i>	A-14
<i>Step 2 – Determine the Positioning Resolution of the Load.</i>	A-14
<i>Step 3 – Determine the Motion Profile</i>	A-14
<i>Step 4 – Determine the Required Motor Torque</i>	A-15
<i>Step 5 – Select and Confirm the Servo Motor and Driver System.</i>	A-15
<i>Engineering Unit Conversion Tables, Formulas, & Definitions.</i>	A-16
Appendix B: Using SureServo® with DirectLOGIC PLCs	B-1
<i>Compatible DirectLOGIC PLCs and Modules</i>	B-2
<i>Typical Connections to a DL05 PLC</i>	B-4
<i>Typical Connections to an H0-CTRIO</i>	B-5
<i>Typical Connections to a DL06 PLC</i>	B-6
<i>Typical DL06 Connections – Multiple Drives/Motors Through Communication</i>	B-7
<i>Connecting SureServo® to ADC Line Driver Encoders.</i>	B-8
<i>Connecting SureServo® to ADC Open-Collector Encoders.</i>	B-9
Appendix C: Latest SureServo® Firmware Revisions	C-1
<i>SureServo® Firmware Identification.</i>	C-2
<i>Overview of Changes in New Firmware Versions.</i>	C-2
<i>Firmware Version 2.105.</i>	C-2
<i>Firmware Version 2.10.</i>	C-2
<i>Drive Operation Changes in Firmware Version 2.10</i>	C-2
<i>Summary of Firmware v2.10 Parameter Changes.</i>	C-3
<i>Detailed Parameter Listings</i>	C-4