

P/N: UBPAK-G (Gray) / UBPAK-B (Black) BACK PANEL ADJUSTMENT KIT Installation Instructions:

The kit consists of the following components:

- Item A) Panel Mount Brackets QTY (4)
- Item B) Thumb Screws, #10-32 X 5/8" Long QTY (4)
- Item C) Pan Head Screws, #10-32 X 3/8" Long QTY (4), (Not Shown)
 - 1) Install Panel Mount Brackets (A) onto the T-rail in the corner of the enclosure.
 - 2) Align bracket T-rail slot to be flush to the top of the enclosures' T-rail.
 - 3) Install and secure Thumb Screw (B) into the lower Panel Mount Bracket's threaded insert and rotate until hand tight.
 - 4) Repeat steps one (1) thru three (3) for each corner, four (4) total.
 - 5) Position Panel (not included) over four (4) upper threaded inserts and secure with Pan Head Screws (C), (x4).
 - 6) Torque four (4) corner panel screws to 25 in-lbs. Max.

Integra Enclosures, Inc.

7750 Tyler Blvd / Mentor, OH 44060 / Voice 440-269-8155 / Fax 440-269-4977 / www.integraenclosures.com (INSTALL SHT-UBPAK_RevA)



P/N: UBPAK-G (Gray) / UBPAK-B (Black) BACK PANEL ADJUSTMENT KIT Installation Instructions:

The kit consists of the following components:

- Item A) Panel Mount Brackets QTY (4)
- Item B) Thumb Screws, #10-32 X 5/8" Long QTY (4)
- Item C) Pan Head Screws, #10-32 X 3/8" Long QTY (4), (Not Shown)
 - 1) Install Panel Mount Brackets (A) onto the T-rail in the corner of the enclosure.
 - 2) Align bracket T-rail slot to be flush to the top of the enclosures' T-rail.
 - 3) Install and secure Thumb Screw (B) into the lower Panel Mount Bracket's threaded insert and rotate until hand tight.
 - 4) Repeat steps one (1) thru three (3) for each corner, four (4) total.
 - 5) Position Panel (not included) over four (4) upper threaded inserts and secure with Pan Head Screws (C), (x4).
 - 6) Torque four (4) corner panel screws to 25 in-lbs. Max.

Integra Enclosures, Inc.

7750 Tyler Blvd / Mentor, OH 44060 / Voice 440-269-8155 / Fax 440-269-4977 / www.integraenclosures.com (INSTALL SHT-UBPAK_RevA)



