

TABLE OF CONTENTS



Chapter 1: Introduction	1-1
Introduction	1-2
Features	1-2
Supported PC Video Modes	1-3
Specifications	1-4
Front and Side Views of Monitors	1-6
ATM1500/ATM1500T	1-6
ATM1700/ATM1700T	1-7
ATM1900/ATM1900T	1-8
Chapter 2: Installation of Monitors	2-1
Installation of Monitor	2-2
Cutout Pattern for Atlas Monitors	2-2
Mounting Clip Installation	2-3
Connecting Power	2-4
Connection of Video and Touch Screen Cables	2-5
Turning on the Computer and Monitor	2-6
Selection of PC Video Settings	2-6
Installing the Touch Screen Driver Software	2-6

Chapter 3: Monitor OSD and Settings	3-1
On Screen Display (OSD) Controls	3-2
Button and LED Functions	3-3
OSD Menus and Settings	3-4
MAIN MENU	3-4
BRIGHTNESS/CONTRAST	3-4
COLOR	3-7
POSITION	3-8
SETUP	3-10
OSD Message Displays	3-13
OUT OF FREQUENCY	3-13
NO SIGNAL	3-13
POWER SAVER MODE	3-14
PROCESSING AUTO CONFIGURATION	3-14
Appendix A: Hardware Connections	A-1
Video Input Pin Assignment	A-2
VGA Pin Assignment	A-3
Touch Screen Pin Assignment	A-4
Serial RS-232	A-4
USB	A-4