

VOLUME TWO:

TABLE OF CONTENTS



Chapter 6: Drum Instruction Programming (DL250-1/DL260 only)	.6-1
Introduction	.6-2
Purpose	.6-2
Drum Terminology	.6-2
Drum Chart Representation	.6-3
Output Sequences	.6-3
Step Transitions	.6-4
Drum Instruction Types	.6-4
Timer-Only Transitions	.6-4
Timer and Event Transitions	.6-5
Event-Only Transitions	.6-6
Counter Assignments	.6-6
Last Step Completion	.6-7
Overview of Drum Operation	.6-8
Drum Instruction Block Diagram	.6-8
Powerup State of Drum Registers	.6-9
Drum Control Techniques	.6-10
Drum Control Inputs	.6-10
Self-Resetting Drum	.6-11
Initializing Drum Outputs	.6-11
Using Complex Event Step Transitions	.6-11
Drum Instruction	.6-12
Timed Drum with Discrete Outputs (DRUM)	.6-12
Event Drum (EDRUM)	.6-14
Handheld Programmer Drum Mnemonics	.6-16

Masked Event Drum with Discrete Outputs (MDRMD)	6-19
Masked Event Drum with Word Output (MDRMW)	6-21
Chapter 7: RLL^{PLUS} Stage Programming	7-1
Introduction to Stage Programming	7-2
Overcoming “Stage Fright”	7-2
Learning to Draw State Transition Diagrams	7-3
Introduction to Process States	7-3
The Need for State Diagrams	7-3
A 2-State Process	7-3
RLL Equivalent	7-4
Stage Equivalent	7-4
Let’s Compare	7-5
Initial Stages	7-5
What Stage Bits Do	7-6
Stage Instruction Characteristics	7-6
Using the Stage Jump Instruction for State Transitions	7-7
Stage Jump, Set, and Reset Instructions	7-7
Stage Program Example: Toggle On/Off Lamp Controller	7-8
A 4-State Process	7-8
Four Steps to Writing a Stage Program	7-9
Stage Program Example: A Garage Door Opener	7-10
Garage Door Opener Example	7-10
Draw the Block Diagram	7-10
Draw the State Diagram	7-11
Add Safety Light Feature	7-12
Modify the Block Diagram and State Diagram	7-12
Using a Timer Inside a Stage	7-13
Add Emergency Stop Feature	7-14
Exclusive Transitions	7-14
Stage Program Design Considerations	7-15
Stage Program Organization	7-15
How Instructions Work Inside Stages	7-16
Using a Stage as a Supervisory Process	7-17
Stage Counter	7-17

Unconditional Outputs	7-18
Power Flow Transition Technique	7-18
Parallel Processing Concepts	7-19
Parallel Processes	7-19
Converging Processes	7-19
Convergence Stages (CV)	7-19
Convergence Jump (CVJMP)	7-20
Convergence Stage Guidelines	7-20
Managing Large Programs	7-21
Stage Blocks (BLK, BEND)	7-21
Block Call (BCALL)	7-22
RLL^{PLUS} (Stage) Instructions	7-23
Stage (SG)	7-23
Initial Stage (ISG)	7-24
Jump (JMP)	7-24
Not Jump (NJMP)	7-24
Converge Stage (CV) and Converge Jump (CVJMP)	7-25
Block Call (BCALL)	7-27
Block (BLK)	7-27
Block End (BEND)	7-27
Stage View in <i>DirectSOFT</i>	7-28
Questions and Answers about Stage Programming	7-29
Chapter 8: PID Loop Operation	8-1
DL250-1 and DL260 PID Loop Features	8-2
Main Features	8-2
Introduction to PID Control	8-4
Why use PID Control?	8-4
Introducing DL205 PID Control	8-6
Process Control Definitions	8-8
PID Loop Operation	8-9
Position Form of the PID Equation	8-9
Reset Windup Protection	8-10
Freeze Bias	8-11
Adjusting the Bias	8-11

Step Bias Proportional to Step Change in SP	8-12
Eliminating Proportional, Integral or Derivative Action	8-12
Velocity Form of the PID Equation	8-12
Bumpless Transfer	8-13
Loop Alarms	8-13
Loop Operating Modes	8-14
Special Loop Calculations	8-14
Ten Steps to Successful Process Control	8-16
PID Loop Setup	8-18
Some Things to Do and Know Before Starting	8-18
PID Error Flags	8-18
Establishing the Loop Table Size and Location	8-18
Loop Table Word Definitions	8-20
PID Mode Setting 1 Bit Descriptions (Addr + 00)	8-21
PID Mode Setting 2 Bit Descriptions (Addr + 01)	8-22
Mode/Alarm Monitoring Word (Addr + 06)	8-23
Ramp/Soak Table Flags (Addr + 33)	8-23
Ramp/Soak Table Location (Addr + 34)	8-24
Ramp/Soak Table Programming Error Flags (Addr + 35)	8-24
PV Auto Transfer (Addr + 36) from I/O Module Base/Slot/Channel Option	8-25
PV Auto Transfer (Addr + 36) from V-memory Option	8-25
Control Output Auto Transfer (Addr + 37)	8-25
Configure the PID Loop	8-26
PID Loop Tuning	8-41
Open-Loop Test	8-41
Manual Tuning Procedure	8-42
Alternative Manual Tuning Procedures by Others	8-44
Tuning PID Controllers	8-44
Auto Tuning Procedure	8-45
Use <i>DirectSOFT</i> Data View with PID View	8-49
Open a New Data View Window	8-49
Open PID View	8-50
Using the Special PID Features	8-52
How to Change Loop Modes	8-52
Operator Panel Control of PID Modes	8-53
PLC Modes Effect on Loop Modes	8-53

Loop Mode Override	8-53
PV Analog Filter	8-54
Creating an Analog Filter in Ladder Logic	8-55
Use the <i>DirectSOFT</i> 5 Filter Intelligent Box (IBOX) Instruction	8-56
FilterB Example	8-56
Ramp/Soak Generator	8-57
Introduction	8-57
Ramp/Soak Table	8-58
Ramp/Soak Table Flags	8-60
Ramp/Soak Generator Enable	8-60
Ramp/Soak Controls	8-60
Ramp/Soak Profile Monitoring	8-61
Ramp/Soak Programming Errors	8-61
Testing Your Ramp/Soak Profile	8-61
DirectSOFT Ramp/Soak Example	8-62
Setup the Profile in PID Setup	8-62
Program the Ramp/Soak Control in Relay Ladder	8-62
Test the Profile	8-63
Cascade Control	8-64
Introduction	8-64
Cascaded Loops in the DL205 CPU	8-65
Tuning Cascaded Loops	8-66
Time-Proportioning Control	8-67
On/Off Control Program Example	8-68
Feedforward Control	8-69
Feedforward Example	8-70
PID Example Program	8-71
Program Setup for the PID Loop	8-71
Troubleshooting Tips	8-74
Glossary of PID Loop Terminology	8-76
Bibliography	8-78
Chapter 9: Maintenance and Troubleshooting	9-1
Hardware Maintenance	9-2

Table of Contents

Standard Maintenance	9-2
Air Quality Maintenance	9-2
Low Battery Indicator	9-2
CPU Battery Replacement	9-2
Diagnostics	9-3
Diagnostics	9-3
Fatal Errors	9-3
Non-fatal Errors	9-3
Finding Diagnostic Information	9-4
V-memory Locations Corresponding to Error Codes	9-4
Special Relays (SP) Corresponding to Error Codes	9-5
I/O Module Codes	9-6
Error Message Tables	9-7
System Error Codes	9-8
Program Error Codes	9-9
CPU Error Indicators	9-10
PWR Indicator	9-11
Incorrect Base Power	9-11
Faulty CPU	9-11
Device or Module causing the Power Supply to Shutdown	9-12
Power Budget Exceeded	9-12
Run Indicator	9-13
CPU Indicator	9-13
BATT Indicator	9-13
Communications Problems	9-13
I/O Module Troubleshooting	9-14
Things to Check	9-14
I/O Diagnostics	9-14
Some Quick Steps	9-15
Testing Output Points	9-16
Handheld Programmer Keystrokes Used to Test an Output Point	9-16
Noise Troubleshooting	9-17
Electrical Noise Problems	9-17
Reducing Electrical Noise	9-17
Machine Startup and Program Troubleshooting	9-18

Syntax Check	9-18
Duplicate Reference Check	9-19
TEST-PGM and TEST-RUN Modes	9-20
Special Instructions	9-22
Run Time Edits	9-24
Forcing I/O Points	9-26
Regular Forcing with Direct Access	9-28
Bit Override Forcing	9-29
Bit Override Indicators	9-29

Appendix A: Auxiliary Functions A-1

Introduction	A-2
What are Auxiliary Functions?	A-2
Accessing AUX Functions via <i>DirectSOFT</i>	A-3
Accessing AUX Functions via the Handheld Programmer	A-3
AUX 2* — RLL Operations	A-4
AUX 21-24	A-4
AUX 21 Check Program	A-4
AUX 22 Change Reference	A-4
AUX 23 Clear Ladder Range	A-4
AUX 24 Clear Ladders	A-4
AUX 3* — V-memory Operations	A-5
AUX 31	A-5
AUX 31 Clear V-Memory	A-5
AUX 4* — I/O Configuration	A-5
AUX 41-46	A-5
AUX 41 Show I/O Configuration	A-5
AUX 42 I/O Diagnostics	A-5
AUX 44 Power-up Configuration Check	A-5
AUX 45 Select Configuration	A-6
AUX 46 to I/O Configuration	A-6
AUX 5* — CPU Configuration	A-7
AUX 51-5C	A-7
AUX 51 Modify Program Name	A-7
AUX 52 Display/Change Calendar	A-7
AUX 53 Display Scan Time	A-8

Table of Contents

AUX 54 Initialize Scratchpad	A-8
AUX 55 Set Watchdog Timer	A-8
AUX 56 CPU Network Address	A-8
AUX 57 Set Retentive Ranges	A-9
AUX 58 Test Operations	A-9
AUX 59 Bit Override	A-10
AUX 5B Counter Interface Configuration	A-10
AUX 5C Display Error History	A-11
AUX 6* — Handheld Programmer Configuration	A-12
AUX 61, 62 and 65	A-12
AUX 61 Show Revision Numbers	A-12
AUX 62 Beeper On/Off	A-12
AUX 65 Run Self Diagnostics	A-12
AUX 7* - EEPROM Operations	A-12
AUX 71 - 76	A-12
Transferrable Memory Areas	A-13
AUX 71 CPU to HPP EEPROM	A-13
AUX 72 HPP EEPROM to CPU	A-13
AUX 73 Compare HPP EEPROM to CPU	A-13
AUX 74 HPP EEPROM Blank Check	A-13
AUX 75 Erase HPP EEPROM	A-13
AUX 76 Show EEPROM Type	A-13
AUX 8* — Password Operations	A-14
AUX 81 - 83	A-14
AUX 81 Modify Password	A-14
AUX 82 Unlock CPU	A-14
AUX 83 Lock CPU	A-14
Appendix B: DL205 Error Codes	B-1
Appendix C: Instruction Execution Times	C-1
Introduction	C-2
V-Memory Data Registers	C-2
V-Memory Bit Registers	C-2
How to Read the Tables	C-2
Boolean Instructions	C-3

Comparative Boolean Instructions	C-4
Bit of Word Boolean Instructions	C-13
Immediate Instructions	C-14
Timer, Counter and Shift Register Instructions	C-15
Accumulator Data Instructions	C-16
Logical Instructions	C-18
Math Instructions	C-20
Differential Instructions	C-23
Bit Instructions	C-24
Number Conversion Instructions	C-25
Table Instructions	C-25
CPU Control Instructions	C-27
Program Control Instructions	C-27
Interrupt Instructions	C-28
Network Instructions	C-28
Intelligent I/O Instructions	C-28
Message Instructions	C-29
RLL ^{PLUS} Instructions	C-29
DRUM Instructions	C-29
Clock / Calender Instructions	C-30
Modbus Instructions	C-30
ASCII Instructions	C-30
Appendix D: Special Relays	D-1
DL230 CPU Special Relays	D-2
Startup and Real-Time Relays	D-2
CPU Status Relays	D-2
System Monitoring	D-2
Accumulator Status	D-3
Counter Interface Module Relays	D-3
Equal Relays for Multi-step Presets with Up/Down Counter #1 / DL230 (for use with a Counter Interface Module)	D-4

DL240/DL250-1/DL260 CPU Special Relays	D-5
Startup and Real-Time Relays	D-5
CPU Status Relays	D-5
System Monitoring Relays	D-6
Accumulator Status Relays	D-6
Counter Interface Module Relays	D-7
Communications Monitoring Relays	D-8
Equal Relays for Multi-step Presets with Up/Down Counter #1 (for use with a Counter Interface Module)	D-9
Equal Relays for Multi-step Presets with Up/Down Counter #2 (for use with a Counter Interface Module)	D-10
Appendix E: PLC Memory	E-1
DL205 PLC Memory	E-2
Non-volatile V-memory in the DL205	E-3
Appendix F: DL205 Product Weight Table	F-1
DL205 Product Weight Table	F-2
Appendix G: ASCII Table	G-1
ASCII Conversion Table	G-2
Appendix H: Numbering Systems	H-1
Introduction	H-2
Binary Numbering System	H-2
Hexadecimal Numbering System	H-3
Octal Numbering System	H-4
Binary Coded Decimal (BCD) Numbering System	H-5
Real (Floating Point) Numbering System	H-5
BCD/Binary/Decimal/Hex/Octal -What is the Difference?	H-6
Data Type Mismatch	H-7
Signed vs. Unsigned Integers	H-8
AutomationDirect.com Products and Data Types	H-9

*Direct*LOGIC PLCsH-9
 C-more/C-more Micro-Graphic PanelsH-9

Appendix I: European Union Directives (CE)I-1

European Union (EU) DirectivesI-2
 Member CountriesI-2
 Applicable DirectivesI-2
 ComplianceI-2
 General SafetyI-3
 Special Installation ManualI-4
 Other Sources of InformationI-4

Basic EMC Installation GuidelinesI-4
 EnclosuresI-4
 AC Mains FiltersI-5
 Suppression and FusingI-5
 Internal Enclosure GroundingI-5
 Equi-potential GroundingI-6
 Communications and Shielded CablesI-6
 Analog and RS232 CablesI-7
 Shielded Cables within EnclosuresI-7
 Analog Modules and RF InterferenceI-8
 Network IsolationI-8
 DC Powered VersionsI-8
 Items Specific to the DL205I-9

Index

Notes