

# Index

---

## A

- Address, assignment, 2–8
- Address Block, 1–7
  - switch assignment, 2–8
  - termination resistor, 2–8
- Application, planning, 1–4

## B

- Back-panel
  - access, 1–7
  - layout, 1–7

## C

- Communications Cable, recommended, 2–9
- Configuration
  - address, 2–7
  - preparation, 4–2
  - software, 4–2
- Configuration Cable, 2–9
- Configuring
  - base register address, 4–6
  - communications, 4–5
  - panel address, 4–6
  - panel functions, 4–6
- Connecting Cable
  - 5/04, 2–9
  - details, 2–10
  - GE Series 1, 2–9
  - pinouts, 2–10
  - SIMATIC TI, 2–9
  - Slice I/O, 2–9
  - TI305, 2–9

- Connecting Cables, 2–9
- Connecting Cbale, TI405, 2–9
- Control Register, 3–4
- CPU, cables, 2–9

## D

- Data Acknowledge, control bit, 3–13
- Data Available, status bit, 3–13
- Decimal point
  - placement, 3–10
  - types, 3–10
- DirectLOGIC, communications table, 4–5
- Dynamic Message
  - bottom line display, 3–9
  - display, 3–7
  - operation, 3–7
  - top line display, 3–8

## F

- Frequently Asked Questions, 1–8

## I

- Interactive Message
    - arrow adjustment, 3–10
    - bottom line display, 3–12
    - numeric keypad, 3–10
    - operations, 3–10
    - status and controlbits, 3–13
    - top line display, 3–11
-

## K

Keypad, entry, 1–6

## L

Label

- creating, 2–3
- installation, 2–2

Lamp

- control example, 3–19
- example, 3–20
- flash example, 3–19, 3–20
- labels, 2–2
- legend, 2–3
- operation, 3–17

Legends, 2–3

## M

Mapping

- control register, 3–25
- DL305 status register, 3–26
- status register, 3–24

Memory

- register assignment, 3–21
- register definition, 3–21

Memory Mapping

- compatible example, 3–25
- DirectLOGIC compatibles, 3–24
- DirectLOGIC example, 3–24
- DL305 example, 3–26
- operation, 3–24
- overview, 3–21
- PLCDirect example, 3–25

Menu

- function select bit, 3–15, 3–16
- menu bits, 3–15
- menu enable bit, 3–16
- operation, 3–5, 3–15
- planning, 3–14

Menu and Sub-Menu, 3–14

Message, display overview, 1–6

Message Display

- operations, 3–5
- types, 3–5

## O

OP–9001, cable connectors, 2–9

OP–9001 Communications Master, 2–8

OP–Panel

- LCD display, 1–6
- memory definition, 3–22
- overview, 1–5
- pushbuttons, 1–5

OP–panel

- configuration mode, 2–7
- features, 3–2
- labels, 2–2
- lamps, 1–6

OPEditor

- configuration cable, 2–7
- configuration software, 4–2
- documentation, 4–3
- installation, 4–4
- system requirements, 4–3
- user steps, 4–4

## P

Panel

- cutout dimensions, 2–4
- mounting dimensions, 2–4

Panel Configuration, problems, 5–2

Power Receptacle, 1–7

Power Supply

- connections, 2–6
- connectors, 2–9
- hook-up, 2–6
- requirements, 2–6

Preparing, labels, 2–2

Pushbutton

- labels, 2–2
- legend, 2–3
- operation, 3–17

## R

RS–422, communications, 2–8

---

## **S**

Serial Port, 1–7

Specification, storage temperature, 2–5

Specifications, 2–5

- communication link, 2–5

- diagnostics, 2–5

- environmental, 2–5

- NEMA rating, 2–5

- power connector, 2–5

Static Message

- display, 3–6

- operation, 3–6

Status and Control

- bit definition, 3–4

- bit-level access, 3–3

- register overview, 3–3

Status Register, 3–4

## **T**

Troubleshooting, Panel to PLC communications, 5–3, 5–4

Troubleshooting, 5–2

## **U**

User Memory, overview, 3–23

---