

# TABLE OF CONTENTS

---



## Chapter 1: Introduction

Introduction.....	1-2
Features.....	1-2
Supported PC Video Modes.....	1-3
Specifications.....	1-4
Front and Side Views of Monitors .....	1-6
ATM1500/ATM1500T .....	1-6
ATM1700/ATM1700T .....	1-7
ATM1900/ATM1900T .....	1-8

## Chapter 2: Installation of Monitor

Installation of Monitor .....	2-2
Cutout Pattern for Atlas Monitors .....	2-2
Mounting Clip Installation .....	2-3
Connecting Power .....	2-4
Optional Protective Cover Installation.....	2-6
Connection of Video and Touch Screen Cables .....	2-7
Turning on the Computer and Monitor .....	2-8
Selection of PC Video Settings.....	2-8
Installing the Touch Screen Driver Software.....	2-8

## Chapter 3: Monitor OSD and Settings

On Screen Display (OSD) Controls .....	3-2
Button and LED Functions.....	3-3
OSD Menus and Settings .....	3-4
MAIN MENU .....	3-4
BRIGHTNESS/CONTRAST .....	3-4
COLOR.....	3-7
POSITION.....	3-8
SETUP.....	3-10
OSD Message Displays .....	3-13
OUT OF FREQUENCY .....	3-13
NO SIGNAL.....	3-13
POWER SAVER MODE.....	3-14
PROCESSING AUTO CONFIGURATION .....	3-14

## Appendix: Hardware Connections

Video Input Pin Assignment.....	A-2
VGA Pin Assignment.....	A-3
Touch Screen Pin Assignment.....	A-4
Serial RS-232 .....	A-4
USB .....	A-4