

Table of Contents

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
Analog Input Module Terminology	1-4
Channels per Module	1-4
Input Ranges	1-4
Resolution	1-4
Input Type	1-4
Input Impedance	1-4
Conversion Method	1-4
PLC Update Rate	1-4
Linearity Error	1-4
Maximum Inaccuracy	1-4
Accuracy vs. Temperature	1-4
I/O Points Required	1-4
External Power Source	1-4
Base Power Required	1-4
Operating Temperature	1-4
Relative Humidity	1-4
Step Response	1-4
Analog Output Module Terminology	1-5
Channels per Module	1-5
Output Ranges	1-5
Resolution	1-5
Output Current	1-5
Output Impedance	1-5
Load Impedance	1-5
PLC Update Rate	1-5
Linearity Error	1-5
Maximum Inaccuracy	1-5
Accuracy vs. Temperature	1-5
External Power Source	1-5
Base Power Required	1-5
Operating Temperature	1-5
Relative Humidity	1-5
I/O Points Required	1-5
Selecting the Appropriate Module	1-6
Wide Variety of Modules	1-6
Diagnostic Features	1-6

Analog Input Modules	1-7
Special Input Modules	1-8
Analog Output Modules	1-9
Physical Characteristics	1-10
Frequently Asked Questions	1-10
Analog Made Easy – Four Simple Steps	1-11

Chapter 2: Installation and Wiring

Safety Guidelines	2-2
Plan for Safety	2-2
Safety Techniques	2-2
Orderly System Shutdown	2-3
System Power Disconnect	2-3
I/O Wiring Strategies	2-4
Wiring Guidelines	2-4
I/O Module Placement and Wiring	2-5
Module Placement	2-5
I/O Module Status Indicators	2-6
Color Coding of I/O Modules	2-6
Wiring a Module with a Terminal Block	2-7

Chapter 3: F4-04AD 4-Channel Analog Input

Module Specifications	3-2
Analog Input Configuration Requirements	3-2
Input Specifications	3-3
General Specifications	3-3
Setting the Module Jumpers	3-4
Jumper Locations	3-4
Factory Default Settings	3-4
Selecting the Number of Active Channels	3-4
Selecting 16 Input or 32 Input Modes	3-5
Operating Range Selection 16 Input Mode	3-6
Operating Range Selection 32 Input Mode	3-7
Units Selection for 32 Input Mode	3-8
Connecting the Field Wiring	3-9
Wiring Guidelines	3-9
User Power Supply Requirements	3-9
Using Current or Voltage Wiring	3-9
Current Loop Transmitter Impedance	3-11
Wiring Diagram	3-11

Module Operation	3-12
DL430 Special Requirements	3-12
Channel Scanning Sequence	3-13
Displaying Diagnostic Data	3-13
Displaying Channel Data	3-14
Input Assignments for 16 Input Mode	3-14
Active Channel Indicator Inputs, 16 Input Mode	3-15
Analog Data Bits, 16 Input Mode	3-15
Sign Bit, 16 Input Mode	3-15
Broken Transmitter Bit, 16 Input Mode	3-15
Input Assignments for 32 Input Mode	3-16
Active Channel Indicator Inputs, 32 Input Mode	3-16
Analog Data Bits, 32 Input Mode	3-17
Sign Bits, 32 Input Mode	3-18
Broken Transmitter bits, 32 Input Mode	3-18
12-Bit Magnitude Plus Sign Format, (All Modes)	3-19
Two's Complement Format, 13-Bit	3-19
Two's Complement Format, 12-Bit	3-21
Unipolar Resolution	3-22
Bipolar Resolution	3-22
Writing the Control Program, 16 Input Mode	3-23
Multiple Active Channels	3-23
Reading Values, DL440/450	3-23
Optional Method, DL440/450	3-24
Reading Values, DL430	3-24
Single Active Channel	3-25
Reading Four Channels in One Scan, DL440/450	3-25
Reading Values With Sign Bits, DL440/450	3-26
Broken Transmitter Detection	3-26
Writing the Control Program, 32 Input Mode	3-27
Multiple Active Channels	3-27
Reading Values, DL440/450	3-28
Reading Values, DL430	3-28
Single Active Channel	3-29
Reading Four Channels in One Scan, DL440/450	3-29
Reading Values With Sign Bits	3-30
Broken Transmitter Detection	3-30
Scaling and Converting the Input Data	3-30
Scaling the Input Data	3-30
16 Input Mode Example	3-31
32 Input Mode Example	3-31
Analog and Digital Value Conversions	3-32
Configuration Cross-Reference, D4-04AD to F4-04AD	3-33
Step 1: 32-Input Mode	3-33
Step 2: Range Selection	3-34
Step 3: Units Selection	3-34
Step 4: Number of Active Channels Selection	3-35

Chapter 4: F4-04ADS 4-Channel Isolated Analog Input

Module Specifications	4-2
Analog Input Configuration Requirements	4-2
Input Specifications	4-3
General Specifications	4-3
Setting the Module Jumpers	4-4
Jumper Locations	4-4
Factory Default Settings	4-4
Selecting the Number of Channels	4-5
Example Settings	4-5
Connecting the Field Wiring	4-7
Wiring Guidelines	4-7
User Power Supply Requirements	4-7
Custom Input Ranges	4-7
Current Loop Transmitter Impedance	4-8
Removable Connector	4-8
Wiring Diagram	4-8
Module Operation	4-9
DL430 Special Requirements	4-9
Channel Scanning Sequence	4-10
Input Bit Assignments	4-11
Active Channel Indicator Inputs	4-11
Analog Data Bits	4-12
Writing the Control Program	4-13
Multiple Channels Selected	4-13
Reading Values, DL440/450	4-13
Reading Values, DL430	4-14
Single Channel Selected	4-14
Reading Four Channels in One Scan, DL440/450 Only	4-15
Scaling the Input Data	4-15
Analog and Digital Value Conversions	4-17

Chapter 5: F4-08AD 8-Channel Analog Input

Module Specifications	5-2
Analog Input Configuration Requirements	5-2
Input Specifications	5-3
General Specifications	5-3
Setting the Module Jumpers	5-4
Jumper Locations	5-4
Selecting the Number of Channels	5-4
Selecting Current or Voltage	5-5
Selecting Input Signal and Ranges	5-5
Connecting the Field Wiring	5-6
Wiring Guidelines	5-6
User Power Supply Requirements	5-6
Custom Input Ranges	5-6

Current Loop Transmitter Impedance	5-7
Removable Connector	5-7
Wiring Diagram	5-8
Module Operation	5-9
DL430 Special Requirements	5-9
Channel Scanning Sequence	5-10
Input Bit Assignments	5-11
Active Channel Indicator Inputs	5-11
Analog Data Bits	5-12
Unusable MSB Bit	5-12
Writing the Control Program	5-13
Multiple Channels Selected	5-13
Reading Values, DL430 CPU	5-14
Single Channel Selected	5-15
Reading Values, DL440/450	5-15
Reading Eight Channels in One Scan, DL440/450	5-16
Scaling the Input Data	5-16
Analog and Digital Value Conversions	5-18

Chapter 6: F4-16AD-1 16-Channel Analog Input

Module Specifications	6-2
Analog Input Configuration Requirements	6-2
Input Specifications	6-3
General Specifications	6-3
Setting the Module Jumpers	6-4
Jumper Locations	6-4
Selecting the Number of Channels	6-5
Selecting Input Ranges	6-5
Connecting the Field Wiring	6-6
Wiring Guidelines	6-6
User Power Supply Requirements	6-6
Current Loop Transmitter Impedance	6-7
Removable Connector	6-8
Wiring Diagram	6-8
Module Operation	6-9
DL430 Special Requirements	6-9
Channel Scanning Sequence	6-10
Input Bit Assignments	6-11
Active Channel Indicator Inputs	6-11
Analog Data Bits	6-12
Writing the Control Program	6-13
Multiple Channels Selected	6-13
Storing the Channel Data to V-Memory	6-13
Reading Values, DL430 CPU	6-14
Single Channel Selected	6-15
Reading Values	6-15
Reading sixteen Channels in One Scan	6-16

Scaling the Input Data	6-16
Analog and Digital Value Conversions	6-18

Chapter 7: F4-16AD-2 8-Channel Analog Input

Module Specifications	7-2
Analog Input Configuration Requirements	7-2
Input Specifications	7-3
General Specifications	7-3
Setting the Module Jumpers	7-4
Jumper Locations	7-4
Selecting the Number of Channels	7-5
Selecting Input Signal Ranges	7-5
Connecting the Field Wiring	7-6
Wiring Guidelines	7-6
User Power Supply Requirements	7-6
Custom Input Ranges	7-7
Removable Connector	7-8
Wiring Diagram	7-8
Module Operation	7-9
D4-430 Special Requirements	7-9
Channel Scanning Sequence	7-10
Input Bit Assignments	7-11
Active Channel Indicator Inputs	7-11
Analog Data Bits	7-12
Writing the Control Program	7-13
Multiple Channels Selected	7-13
Storing the Channel Data to V-Memory	7-13
Reading Values	7-14
Single Channel Selected	7-15
Reading Values	7-15
Reading Sixteen Channels in One Scan	7-16
Scaling the Input Data	7-16
Analog and Digital Value Conversions	7-18

Chapter 8: F4-08THM-n 8-Channel Thermocouple Input

Module Specifications	8-2
Input Specifications	8-3
General Specifications	8-3
Module Calibration	8-4
Thermocouple Input Configuration Requirements	8-4
Setting the Module Jumpers	8-4
Jumper Locations	8-4
Factory Default Settings	8-4
Selecting the Number of Channels	8-5
Selecting Fahrenheit or Celsius	8-5
Selecting Temperature or Counts	8-6

Connecting the Field Wiring	8-6
Wiring Guidelines	8-6
User Power Supply Requirements	8-6
Wiring Diagram	8-7
Module Operation	8-8
DL430 Special Requirements	8-8
Channel Scanning Sequence	8-9
Identifying the Data Locations	8-10
Active Channel Indicator Inputs	8-10
Temperature Sign Bit	8-11
Analog Data Bits	8-11
Temperature Input Resolution	8-11
Millivolt Input Resolution	8-11
Writing the Control Program	8-12
Multiple Channels Selected	8-12
Automatic Temperature Conversion	8-12
Reading Values, DL430	8-13
Single Channel Selected	8-14
Reading Values, DL440/450	8-14
Reading Eight Channels in One Scan, DL440/450	8-15
Using the Sign Bit, DL440/450	8-16
Scaling the Input Data	8-17
Temperature and Digital Value Conversions	8-18
Millivolt and Digital Value Conversions	8-18

Chapter 9: F4-08RTD 8-Channel RTD Input

Module Specifications	9-2
Module Calibration	9-2
RTD Input Configuration Requirements	9-2
Input Specifications	9-3
General Specifications	9-3
Setting the Module Jumpers	9-4
Jumper Locations	9-4
Factory Default Settings	9-4
Selecting Fahrenheit or Celsius	9-4
Selecting RTD Type	9-5
Selecting the Number of Channels	9-6
Connecting the Field Wiring	9-7
Wiring Guidelines	9-7
RTD – Resistance Temperature Detector	9-7
Ambient Variations in Temperature	9-7
Wiring Diagram	9-8
Module Operation	9-9
DL430 Special Requirements	9-9
Channel Scanning Sequence	9-10
Identifying the Data Locations	9-11

Writing the Control Program	9-12
Multiple Active Channels	9-12
Analog Data and Sign Bits	9-12
Active Channel Bits	9-13
Broken Transmitter Bits	9-13
Reading Values, DL430	9-13
Reading Values, DL440/450	9-14
Reading Eight Channels in One Scan, DL440/DL450	9-15
Using Bipolar Ranges (Magnitude Plus Sign)	9-16
Using Bipolar Ranges Example Continued	9-17
Reading the Input Data	9-17

Chapter 10: F4-08THM 8-Channel Thermocouple Input

Module Specifications	10-2
General Specifications	10-2
Thermocouple Specifications	10-3
Voltage Specifications	10-3
Module Calibration	10-3
Thermocouple Input Configuration Requirements	10-3
Setting the Module Jumpers	10-4
Jumper Locations	10-4
Calibrate Enable	10-4
Selecting the Number of Channels	10-5
Setting Input Type	10-6
Selecting the Conversion Units	10-6
Thermocouple Conversion Units	10-6
Voltage Conversion Units	10-7
Connecting the Field Wiring	10-8
Wiring Guidelines	10-8
User Power Supply Requirements	10-8
Thermocouples	10-9
Ambient Variations in Temperature	10-9
Wiring Diagram	10-10
Module Operation	10-11
DL430 Special Requirements	10-11
Channel Scanning Sequence	10-12
Identifying the Data Locations	10-13
Writing the Control Program	10-14
Multiple Active Channels	10-14
Analog Data and Sign Bits	10-14
Active Channel Bits	10-15
Broken Transmitter Bits	10-15
Reading Values, DL430	10-15
Reading Values, DL440/450	10-16
Using Bipolar Ranges (Magnitude Plus Sign)	10-17
Using Bipolar Ranges Example Continued	10-18
Reading the Input Data	10-18
Module Resolution 16-Bit (Unipolar Voltage Input)	10-19

Module Resolution 15-Bit Plus Sign (Bipolar Voltage Input)	10–19
Analog and Digital Value Conversions	10–20

Chapter 11: D4-02DA 2-Channel Analog Output

Module Specifications	11–2
Analog Output Configuration Requirements	11–2
Output Specifications	11–3
General Module Specifications	11–3
Connecting the Field Wiring	11–4
Wiring Guidelines	11–4
User Power Supply Requirements	11–4
Load Requirements	11–4
Using the 1–5 VDC Range	11–4
Wiring Diagram	11–5
Module Operation	11–6
DL430 Special Requirements	11–6
Channel Scanning Sequence	11–7
Output Bit Assignments	11–8
Analog Data Bits	11–9
Writing the Control Program	11–10
Update Either Channel	11–10
Calculating the Digital Value	11–10
Sending the Data to the Module	11–11
Analog and Digital Value Conversions	11–12

Chapter 12: F4–04DA 4-Channel Analog Output

Module Specifications	12–2
Analog Output Configuration Requirements	12–2
Output Specifications	12–3
General Module Specifications	12–3
Setting the Module Jumpers	12–4
Jumper Locations	12–4
Selecting Common Output Signal Ranges	12–4
Selecting Special Signal Ranges	12–5
Connecting the Field Wiring	12–6
Wiring Guidelines	12–6
User Power Supply Requirements	12–6
Load Requirements	12–7
Removable Connector	12–7
Wiring Diagram	12–7
Module Operation	12–8
DL430 Special Requirements	12–8
Channel Scanning Sequence	12–9
Output Bit Assignments	12–10
Channel Select Bits	12–10
Analog Data Bits	12–11

Writing the Control Program	12-12
Update Any Channel	12-12
Calculating the Digital Value	12-12
Engineering Unit Conversion	12-13
Sending Data to One Channel	12-14
Sending the Same Data to All Channels	12-15
Sequencing the Channel Updates	12-16
Sequencing Example 1, DL440/450	12-17
Sequencing Example 2, DL430	12-18
Sequencing Example 3, DL440/450	12-19
Example 3 Continued	12-20
Sequencing Example 4, DL430	12-21
Example 4 Continued	12-22
Updating All Channels in a Single Scan, DL440/450	12-23
Analog and Digital Value Conversions	12-24

Chapter 13: F4-04DA-1 4-Channel Analog Current Output

Module Specifications	13-2
Output Specifications	13-2
General Module Specifications	13-3
Setting the Module Jumpers	13-3
Connecting the Field Wiring	13-4
Wiring Guidelines	13-4
User Power Supply Requirements	13-4
Load Requirements	13-4
Removable Connector	13-5
Wiring Diagram	13-5
Module Operation	13-6
DL430 Special Requirements	13-6
Analog Output Configuration Requirements	13-7
Channel Update Sequence	13-7
Output Bit Assignments	13-8
Channel Select Bits	13-8
Output Enable Bit	13-9
Analog Data Bits	13-9
Module Resolution	13-9
Writing the Control Program	13-10
Update Any Channel	13-10
Calculating the Digital Value	13-10
V-Memory Registers	13-11
Sending Data to One Channel	13-12
Sequencing the Channel Updates	13-13
Sequencing Example 1, DL440/450	13-14
Sequencing Example 2, DL430	13-15
Sequencing Example 3, DL440/DL450	13-16
Sequencing Example 4, DL430	13-18
Updating all Channels in a Single Scan	13-20
Analog and Digital Value Conversions	13-21

Chapter 14: F4–04DA–2 4-Channel Analog Voltage Output

Module Specifications	14–2
Analog Output Configuration Requirements	14–2
Output Specifications	14–3
General Module Specifications	14–3
Setting the Module Jumpers	14–4
Jumper Locations	14–4
Factory Default Settings	14–4
Voltage Range Selection	14–4
Data Format Selection	14–6
Connecting the Field Wiring	14–7
Wiring Guidelines	14–7
User Power Supply Requirements	14–7
Load Requirements	14–8
Removable Connector	14–8
Wiring Diagram	14–8
Module Operation	14–9
DL430 Special Requirements	14–9
Channel Scanning Sequence	14–10
Output Bit Assignments	14–11
Channel Select Bits	14–11
Analog Data Bits	14–12
Signal Sign Bit	14–12
Bipolar Output Data	14–12
Output Enable Bit	14–13
Module Resolution	14–13
Writing the Control Program	14–14
Update Any Channel	14–14
Calculating the Digital Value	14–14
V-Memory Registers	14–15
Sending Data to One Channel	14–16
Sequencing the Channel Updates	14–17
Sequencing Example 1, DL440/450	14–18
Sequencing Example 2, DL430	14–19
Sequencing Example 3, DL440/DL450	14–20
Sequencing Example 4, DL430	14–22
Sequencing Example 5, Bipolar Data	14–24
Updating all Channels in a Single Scan, DL440/450	14–26
Analog and Digital Value Conversions	14–27
Configuration Cross-Reference, F4–04DA to F4–04DA–2	14–28
Step 1: Select the Compatibility Mode	14–28
Step 2: Voltage Range Selection	14–29

Chapter 15: F4–08DA–1 8-Channel Analog Current Output

Module Specifications	15–2
Analog Output Configuration Requirements	15–2
Output Specifications	15–3
General Module Specifications	15–3
Connecting the Field Wiring	15–4
Wiring Guidelines	15–4
User Power Supply Requirements	15–4
Load Requirements	15–4
Removable Connector	15–5
Wiring Diagram	15–5
Module Operation	15–6
DL430 Special Requirements	15–6
Channel Scanning Sequence	15–7
Output Bit Assignments	15–8
Channel Select Bits	15–8
Output Enable Bit	15–9
Analog Data Bits	15–9
Module Resolution	15–9
Writing the Control Program	15–10
Update Any Channel	15–10
Calculating the Digital Value	15–10
V-Memory Registers	15–11
Sending Data to One Channel	15–12
Sequencing the Channel Updates	15–13
Sequencing Example 1, DL440/450	15–14
Sequencing Example 2, DL430	15–17
Sequencing Example 3, DL440/450	15–18
Sequencing Example 4, DL430	15–20
Updating all Channels in a Single Scan, DL440/450	15–22
Updating a Single Channel During a Scan, DL440/450	15–24
Analog and Digital Value Conversions	15–24

Chapter 16: F4–16DA–1 16-Channel Analog Current Output

Module Specifications	16–2
Analog Output Configuration Requirements	16–2
Output Specifications	16–3
General Module Specifications	16–3
Connecting the Field Wiring	16–4
Wiring Guidelines	16–4
User Power Supply Requirements	16–4
Load Requirements	16–4
Removable Connector	16–5
Wiring Diagram	16–5
Module Operation	16–6
DL430 Special Requirements	16–6

Channel Scanning Sequence	16-7
Output Bit Assignments	16-8
Channel Select Bits	16-9
Output Enable Bits	16-9
Analog Data Bits	16-10
Module Resolution	16-10
Writing the Control Program	16-11
Update Any Channel	16-11
Calculating the Digital Value	16-11
V-Memory Registers	16-12
Sending Data to One Channel, DL440/450	16-13
Sequencing the Channel Updates	16-14
Sequencing Example 1, DL440/450	16-15
Sequencing Example 2, DL430	16-18
Sequencing Example 3, DL440/450	16-19
Sequencing Example 4, DL430	16-22
Updating All Channels in a Single Scan, DL440/450	16-25
Updating a Pair of Channels in a Single Scan, DL440/450	16-27
Analog and Digital Value Conversions	16-28

Chapter 17: F4-04DAS-1 4-Channel Iso. 4-20mA Output

Module Specifications	17-2
Analog Output Configuration Requirements	17-2
Output Specifications	17-3
General Module Specifications	17-3
Connecting the Field Wiring	17-4
Wiring Guidelines	17-4
Removable Connector	17-4
Wiring Diagram	17-4
Module Operation	17-5
DL430 Special Requirements	17-5
Channel Scanning Sequence	17-6
Output Bit Assignments	17-7
Channel Select Bits	17-7
Analog Data Bits	17-8
Output Enable Bit	17-8
Module Resolution	17-8
Writing the Control Program	17-9
Update Any Channel	17-9
Calculating the Digital Value	17-9
Engineering Unit Conversion	17-10
V-Memory Registers	17-10
Sending Data to One Channel	17-11
Sequencing the Channel Updates	17-12
Sequencing Example 1, DL430/440/450	17-13
Sequencing Example 2, DL430/440/450	17-14
Updating all Channels in a Single Scan, DL440/450	17-15
Analog and Digital Value Conversions	17-16

Chapter 18: F4–04DAS–2 4-Channel Isolated Volt Output

Module Specifications	18–2
Analog Output Configuration Requirements	18–2
Output Specifications	18–3
General Module Specifications	18–3
Setting the Module Jumpers	18–4
Output Range Selection	18–4
Connecting the Field Wiring	18–5
Wiring Guidelines	18–5
Removable Connector	18–5
Wiring Diagram	18–5
Module Operation	18–6
D4–430 Special Requirements	18–6
Channel Scanning Sequence	18–7
Output Bit Assignments	18–7
Channel Select Bits	18–8
Analog Data Bits	18–9
Output Enable Bit	18–9
Module Resolution	18–9
Writing the Control Program	18–10
Update Any Channel	18–10
Calculating the Digital Value	18–10
Engineering Unit Conversion	18–11
V-Memory Registers	18–11
Sending Data to One Channel	18–12
Sequencing the Channel Updates	18–13
Sequencing Example 1	18–14
Sequencing Example 2	18–15
Updating all Channels in a Single Scan	18–16
Analog and Digital Value Conversions	18–17

Chapter 19: F4–08DA–2 8-Channel Analog Voltage Output

Module Specifications	19–2
Analog Output Configuration Requirements	19–2
Output Specifications	19–3
General Module Specifications	19–3
Setting the Module Jumper	19–4
Connecting the Field Wiring	19–4
Wiring Guidelines	19–4
User Power Supply Requirements	19–4
Load Requirements	19–4
Removable Connector	19–5
Wiring Diagram	19–5
Module Operation	19–6
D4–430 Special Requirements	19–6

Channel Scanning Sequence	19-7
Output Bit Assignments	19-8
Channel Select Bits	19-8
Output Enable Bit	19-9
Analog Data Bits	19-9
Module Resolution	19-9
Writing the Control Program	19-10
Update Any Channel	19-10
Calculating the Digital Value	19-10
V-Memory Registers	19-11
Sending Data to One Channel	19-12
Sequencing the Channel Updates	19-13
Sequencing Example 1, D4-440/450	19-14
Sequencing Example 2, D4-430	19-17
Sequencing Example 3, D4-440/450	19-18
Sequencing Example 4, D4-430	19-20
Updating all Channels in a Single Scan, D4-440/450	19-22
Updating a Single Channel During a Scan, D4-440/450	19-24
Analog and Digital Value Conversions	19-24

Chapter 20: F4-16DA-2 16-Channel Analog Voltage Output

Module Specifications	20-2
Analog Output Configuration Requirements	20-2
Output Specifications	20-3
General Module Specifications	20-3
Setting the Module Jumpers	20-4
Connecting the Field Wiring	20-4
Wiring Guidelines	20-4
User Power Supply Requirements	20-4
Load Requirements	20-5
Removable Connector	20-5
Wiring Diagram	20-5
Module Operation	20-6
D4-430 Special Requirements	20-6
Channel Scanning Sequence	20-7
Output Bit Assignments	20-8
Channel Select Bits	20-9
Output Enable Bits	20-9
Analog Data Bits	20-10
Module Resolution	20-10
Writing the Control Program	20-11
Update Any Channel	20-11
Calculating the Digital Value	20-11
V-Memory Registers	20-12
Sending Data to One Channel, D4-440/450	20-13
Sequencing the Channel Updates	20-14
Sequencing Example 1, D4-440/450	20-15
Sequencing Example 2, D4-430	20-18

Sequencing Example 3, D4-440/450	20-19
Sequencing Example 4, D4-430	20-22
Updating All Channels in a Single Scan, D4-440/450	20-25
Updating a Pair of Channels in a Single Scan, D4-440/450	20-27
Analog and Digital Value Conversions	20-28

Appendix A: DL405 Discrete I/O Memory Map

X Input / Y Output Bit Map	A-2
Control Relay Bit Map	A-4
Remote I/O Bit Map	A-8
Stage Control / Status Bit Map	A-11
