## Rhino Buffer Module PSM24-BFM600S Operating Instructions





# **RHINO BUFFER MODULE PSM24-BFM600S**

#### Description

The PSM24-BFM600S Buffer Module will hold the output voltage of a 24 VDC power supply after brownouts or voltage dips of up to ten full 50 Hz cycles (200ms at 25 amps). During this buffer period, no deterioration of the 24 VDC output voltage will occur. This buffer module is an ideal and cost effective alternative to a battery-based backup system for many applications. The buffer module consists of a large bank of capacitors.

When the power supply is switched on, the buffer capacitors will be charged. This will take approximately 30 seconds. An opto-coupler signal indicates the "READY" condition.

When a power failure occurs, the capacitor bank is discharged, maintaining the output of the buffer module at its nominal voltage. This condition is indicated by a "POWER FAIL" signal.

The hold-up time is typically 200 ms at 25 amps and 4 seconds, typically, at 1.2 amps. After 4 seconds, the buffer device will switch off the output voltage.

The operation modes of the module are also indicated by an LED on the front panel. The greatest advantage of this buffer solution is that it is fully maintenance free, and its storage capability does not deteriorate over the lifetime of the product.

A 24VDC power supply must be connected to the load as well as to the PSM24-BFM600S module. The buffer module is in parallel to the output voltage of the power supply, and charges its internal hold-up capacitors during normal operation. The charge current (<0.6 A) is taken from the power supply output itself (charging time 30 sec max).

The output voltage is monitored, and if it drops below an adjusted threshold, the PSM24-BFM600S will switch off. The stored energy in the hold-up capacitors is used to keep the output voltage at the threshold level. The quiescent current is 100 mA typ (typ 2.5 W). The output voltage of the power supply must be one volt higher than the threshold level adjusted by the potentiometer. The threshold level can be adjusted in two different ways:

Option 1: At the factory, the PSM24-BFM600S is charged and then discharged with no load, giving the operator approximately 4s to set the threshold level. Option 2: (Less accurate) Turn the PSM24-BFM600S potentiometer fully clockwise and connect the PSM24-BFM600S to a DC supply or the PSM power supply unit set to the correct level (22.5 V for 24 VDC output voltage use). Turn the Buffer potentiometer counter-clockwise until the charging LED starts flashing Green/Red.

The PSM24-BFM600S is a built-in unit. The mounting position must fulfill the requirements for fireproof enclosures, according to UL60950 IEC/EN 60950 or other appropriate national standard. The relevant UL regulations or equivalent national regulations must be observed during installation.

The PSM24-BFM600S is designed for mounting on a DIN rail (DIN EN 50022-35x15/7.5).

The module is not protected against reverse input polarity.



Warning The PSM24-BFM600S built-in module is designed especially for use in process automation and other industrial applications. Components with dangerously high voltage and high stored energy are located in the device; however, these are inaccessible. Failure to properly maintain the PSM24-BFM600S can result in death, severe personal injury or substantial property damage.

The PSM24-BFM600S should be installed and put into operation by qualified personnel only. The corresponding national regulations (e.g. UL, ANSI, VDE, DIN) must be observed. The successful and safe operation of this module is dependent on proper storage, handling, installation and operation. The potentiometer to adjust the output voltage must be actuated using only an insulated screwdriver, because accidental contact may be made with parts inside the power supply carrying dangerous voltages.

Caution: Risk of electrical shock and electrical discharge. Only qualified and trained personnel should open the PSM24-BFM600S or the power supply. Do not open the PSM24-BFM600S or the power supply until at least 5 minutes after complete disconnection of the main power. Electrostatic sensitive device. In case of non-observance or exceeding the limiting value mentioned in these instructions, the function and electrical safety can be impaired and can destroy the PSM24-BFM600S and/or the power supply.

Danger: Never work on the PSM24-BFM600S or power supplies if power is applied! Before installation ensure that the main switch is switched off and locked out. Touching of any live components or improper usage of PSM24-BFM600S or power supply can result in severe injury or death.



Warning: To minimize the risk of potential safety problems, follow all applicable local and national codes regulating the installation and operation of this equipment. These codes vary from area to area and it is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes. Failure to follow all applicable codes, or exceeding the limiting value can impair the function and electrical safety and destroy the power supply. Serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication to be suitable for your particular application, nor do we assume any responsibility for your product design, installation or operations.

#### **Before operating**

- Read these operating instructions carefully and completely.
- Check that the input wiring is sufficiently protected and is the correct size.
- Check that the output wiring is rated for the maximum output current, and connected with the correct polarity.
- Verify that protective ground is adequately sized and properly connected.
- Verify that sufficient cooling is assured.
- Caution: The temperature of the housing can become very high, depending on the ambient temperature and load.



### Installation

#### Assembly

A sufficiently strong DIN rail, such as DN-R35S1, must be used. The module shall be mounted upright on a horizontally mounted DIN rail. A minimum free space of 80 mm [3.15 in.] is required above and below the PSM24-BFM600S; leave a minimum space of 50 mm [1.97 in.] (which allows air convection) on each side. The air temperature, as measured 10 mm [0.39 in.] below the device, shall not exceed 70°C. The load shall be derated at 1.5% per °C above 40 °C. Consider, too, the temperature limits and derating specifications of the connected power supply.

To attach PSM24-BFM600S to the DIN rail, hook top part of clip on DIN rail, then push down and inward until you hear a clicking sound.

To remove the device, pull the latch of the clip using an insulated flathead screwdriver. When the clip has cleared the bottom DIN rail, remove the screwdriver from the recess. Lift the module off the DIN rail.

Wall mounting or chassis mounting can be achieved by use of the optional mounting bracket, PSM-PANEL1. Remove the DIN clips by removing the screw and place the mounting brackets in the same place as the DIN clips. Use the countersink screws included with the wall mounting kit to attach the mounting brackets to the PSM24-BFM600S (tightening torque 0.8-0.9Nm).

#### **Connecting Cable**

Allow only qualified personnel to install the module. The device is equipped with a COMBICON connector. This reliable and easy-to-assemble connection method provides a quick connection of the module.

#### Input (Connector J1 pin 1 & pin 2)

The connection is made by using the –Vin and +Vin connections (connector J1 pin 1, pin 2, pin 3 and pin 4) as well as protective earth (connector J1 pin 5) following local codes and regulations. Choose correct wiring size from the Connections and Terminal Assignment table below.

To achieve a reliable and shockproof connection, strip the connecting ends as listed in the following table. Flexible wires shall be terminated using ferrules.

#### Signaling (Connector J2 pin 3, pin 4, pin 5 and pin 6)

The output "Active" is for enabling monitoring of the functions when the PSM24-BFM600S is in operation. This signal is detected by measuring the input voltage at the input pins, and is provided by an open collector opto-coupler which can handle 10 mA maximum (connector J2 pin 3 and pin 4).

The output "Ready" provides the signal when the PSM24-BFM600S is ready to provide the current (connector J2 pin 5 and pin 6). The "Ready" signal is provided by an open collector opto-coupler which can handle 10 mA. It is detected by measuring the PSM24-BFM600S voltage level at the capacitors.

#### Status LED

The Status LED indicates the status of the PSM24-BFM600S module and provides visual confirmation of the function.

Status LED Function			
LED Green	Normal operation, PSM24-BFM600S is ready to provide a current of 25 A max		
LED Red	Input voltage on PSM24-BFM600S is lower than the adjusted threshold level		
LED Changing from Green to Red	The power supply is charging the PSM24-BFM600S module		
LED Green pulsing	PSM24-BFM600S is providing output current, discharging of PSM24-BFM600S		

#### Inhibit Function

The PSM24-BFM600S unit provides an Inhibit function by use of pin 1 and pin 2 at connector J2 to control the PSM24-BFM600S module. To switch off the PSM24-BFM600S, a voltage level between 5 VDC and 28 VDC is applied on connector J2 pin 1 (Inhibit GND) and connector J2 pin 2 (Inhibit +). The device is ready to provide the output current for the requested buffer time when an open connection or 0–1VDC is applied between J2 pin 1 (Inhibit GND) and pin 2 (Inhibit +).

#### **Operating Temperature Ranges and load derating:**

Operating temperature ranges and load derating depend on the PSM power supply connected to the PSM24-BFM600S. Please see operating temperature range and load derating values listed in the operating instructions for the applicable PSM power supplies.

## **Technical Specifications**

Specifications				
Part Number	Input	Buffer Time	* Output Voltage Range	**Max. Output Current
PSM24-BFM600S	24 VDC power supply	Load dependent 200 ms @ 25 A, 4 s @ 1.2 A load	22 VDC to 28 VDC	25.0 A (600 W)

Output Specifications				
Threshold Adjustable Range with Potentiometer		22 to 28 VDC*		
Ripple and Noise (20MHz Bandwidth)	At <sup>V</sup> in nom and <sup>I</sup> out max	200 mV peak-to-peak max		
Parallel Operation		2 devices possible		

\*Output voltage adjustable,\*\* Maximum current at Vout nom.

\*>1 V below input voltage, min. 22 VDC

General Specifications				
Charging	0.6 A max/30s max			
Inhibit Input	Opto-coupler input: supply between 5 VDC and 28 VDC to Inhibit			
Signal Output Ratings	10 mA @24 VDC			
Temperature	Operating (ambient): -25°C to + 70°C max (-13°F to 158°F). Above +40°C(104°F) load derating Storage (non-operating): -25°C to + 85°C max (-13°F to 185°F). Temperature drift: 0.02%/K. Cooling: convection, no internal fan			
Reliability, Calculated MTBF	In accordance with IEC 61709 L 350,000 hours			
Humidity	95% (non-condensing) relative humidity maximum			
Isolation	According to IEC/EN 60950, UL 60950, UL 508C, EN50178, EN61558-2-8, EN60204			
Output Regulation	Input variation: 0.5% maximum. Load variation (10 to 100%): 0.5% maximum			
Output Voltage Ripple	100 mV peak to peak typical (20 MHz bandwidth), (200 mV peak-to-peak maximum at Imax)			
Vibration	IEC 60068-2-6: 3 axis, sine sweep, 10-55 Hz, 1g, 1 oct/min			
Shock	IEC 60068-2-27: 3 axis, 15g half sine, 11ms			
Enclosure Rating	IP20 (IEC 529)			
Enclosure Material	Aluminum (chassis) / zinc plated steel (cover)			
Mounting	Snap-on with self-locking spring for 35mm DIN rails per EN 50022-35x15/75, or wall mount with bracket			
Connection	Pluggable screw terminals (plugs included)			
General Specifications – Safety Standards				
Specification	Standard	Document Number		
Electromagnetic Compatibility (EMC), Emissions	EMC, Emissions	Corresponds to connected units ( no internal switching device)		
Electromagnetic Compatibility (EMC), Immunity	EMC, Immunity	Corresponds to connected units ( no internal switching device)		
Pollution Degree	2	n/a		

#### Buffer Time vs Load Power (typical values)





#### **Buffer Module Function Diagram and Connector Positions**





	J1	J2
Pin 1	+ Vin	Inhibit GND
Pin 2	+ Vin	Inhibit +
Pin 3	- Vin	Active GND
Pin 4	- Vin	Active Signal
Pin 5	FG	Ready GND
Pin 6	—	Ready Signal
Conductor size	0.5-4.0 mm <sup>2</sup> (24-10 AWG)*	0.2-2.5 mm <sup>2</sup> (32-12 AWG)
Torque	0.5-0.6 Nm	0.5-0.6 Nm
Stripping length	7mm	7mm
* Use conductor size appropriate for connected power supply.		

#### Dimensions

Unit: mm [inches]





Side view

