

# TABLE OF CONTENTS

---



Chapter 1: Getting Started . . . . .	1-1
Manual Overview . . . . .	1-2
<i>SureStep</i> <sup>™</sup> System Introduction . . . . .	1-3
Microstepping Drives Introduction . . . . .	1-4
Bipolar Step Motor Introduction . . . . .	1-6
Stepping System Power Supply Introduction . . . . .	1-7
Selecting the Stepping System . . . . .	1-8
Use with <i>Direct</i> LOGIC PLCs . . . . .	1-8
Chapter 2: <i>SureStep</i> <sup>™</sup> STP-DRV-4035 Microstepping Drive . . . . .	2-1
Features . . . . .	2-2
Block Diagram . . . . .	2-2
Specifications . . . . .	2-3
Typical Wiring Diagram . . . . .	2-4
Connection and Adjustment Locations . . . . .	2-4
The Enable Input . . . . .	2-9
Setting Phase Current . . . . .	2-10
Microstepping . . . . .	2-12
Idle Current Reduction . . . . .	2-13
Self Test . . . . .	2-13
Choosing a Power Supply . . . . .	2-14
Mounting the Drive . . . . .	2-15
Dimensions . . . . .	2-16

Chapter 3: *SureStep*<sup>™</sup> Advanced Microstepping Drives . . .3-1

- Features . . . . .3-2
- Specifications . . . . .3-3
- Typical Wiring Diagram . . . . .3-4
- Connection Locations & Pin-out . . . . .3-4
- Connecting the Motor . . . . .3-5
- Connecting the Power Supply . . . . .3-6
- Connecting the I/O . . . . .3-7
- Drive Configuration . . . . .3-11
- SureStep* Pro Software . . . . .3-13
- Choosing a Power Supply . . . . .3-16
- Mounting the Drive . . . . .3-17
- Dimensions and Mounting Slot Locations . . . . .3-17

Chapter 4: *SureStep*<sup>™</sup> Stepping Motors . . . . .4-1

- Features . . . . .4-2
- Design and Installation Tips . . . . .4-2
- Specifications . . . . .4-3
- Power Supply and Step Motor Drive . . . . .4-4
- Mounting the Motor . . . . .4-4
- Connecting the Motor . . . . .4-4
- Motor Dimensions and Cabling . . . . .4-5
- Torque vs. Speed Charts . . . . .4-7

Chapter 5: *SureStep*<sup>™</sup> Stepping System Power Supplies .5-1

- Features . . . . .5-2
- Specifications . . . . .5-3
- Power Supply Terminal & Component Layout . . . . .5-4
- Mounting the Power Supply . . . . .5-5
- Dimensions . . . . .5-6

---

Appendix A: Selecting the <i>SureStep</i> <sup>™</sup> Stepping System . . .	A-1
Selecting the <i>SureStep</i> <sup>™</sup> Stepping System . . . . .	A-2
Leadscrew - Example Calculations . . . . .	A-8
Belt Drive - Example Calculations . . . . .	A-11
Index Table - Example Calculations . . . . .	A-14
Engineering Unit Conversion Tables, Formulae, & Definitions: . . . . .	A-17
 Appendix B: Using <i>SureStep</i> <sup>™</sup> with AutomationDirect PLCs . . . . .	 B-1
Compatible <i>Direct</i> LOGIC PLCs and Modules . . . . .	B-2
Typical Connections to a DL05 PLC . . . . .	B-4
Typical Connections to an H0-CTRIO . . . . .	B-5
Typical Connections – Multiple Drive/Motors . . . . .	B-6
Typical <i>Direct</i> LOGIC PLC Serial Connections to an Advanced <i>SureStep</i> Drive . . . . .	 B-7
Typical CLICK & P3000 PLC Serial Connections to an Advanced <i>SureStep</i> Drive . . . . .	 B-8

BLANK  
PAGE