


Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.




HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide

Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.




HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide

Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.




HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide

Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.




HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide

Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.




HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide

Installation

- System piping should be the same pipe size as regulator ports. Locate regulator as close as possible to the device using regulated water. If cycling devices are used in the piping system, install the regulator upstream of these devices. A filter installed upstream of the regulator is recommended to maximize service life.
- The arrow on the regulator body indicates direction of water flow. Connect piping to the proper ports using pipe sealant on male threads only. Do not allow sealant to enter interior of regulator. Regulator can be installed at any angle.
- Two 1/8" NPT gauge ports are provided to allow for the connection of an outlet pressure gauge or as additional outlets for regulated water. Plug unused gauge ports. Panel-mounted units require 1-3/16" diameter hole with maximum panel thickness of 1/4".

Operation

- Prior to turning on supply water, back off adjusting screw (counter clockwise) until there is no compression of the range spring.
- After applying the water supply, outlet pressure can be increased by rotating the adjustment screw clockwise. Pressure can be decreased by turning counter clockwise.
- Push knob inward to lock pressure setting.



HydroMode Regulators
Copyright 2015, *Automationdirect.com* Incorporated/All Rights Reserved Worldwide