

Polycarbonate Latch Kit: KIT-GPCL

See Figure A

Included are four ea. of the following:

2424 Lower Latch #(24241045)

2424 Upper Latch #(24241050).

Assemble Upper Latch into Lower Latch by snapping the two pieces together as shown.

See Figure B

Position Upper Latch over lip on lid and position pivot axial diameter over the V Latch mount feature as shown.

See Figure C

Pull down the Lower Latch, which will cause the attachment to the base, by snapping in the pivot axial diameter to the latch mount feature.

See Figure D

To meet UL 4X-6P requirement, Latches to be placed as follows: Two latch assemblies attached to the right side, one on the bottom, and one on the top as shown. Four places. Extra Latches available, but not required.

