

Polycarbonate Latch Kit: KIT-GPCL-2PK

See Figure A

Included are two (2) ea. of the following:

2424 Lower Latch #(24241045)

2424 Upper Latch #(24241050).

Assemble Upper Latch into Lower Latch by snapping the two pieces together as shown.

See Figure B

Position Upper Latch over lip on lid and position pivot axial diameter over the V Latch mount feature as shown.

See Figure C

Pull down the Lower Latch, which will cause the attachment to the base, by snapping in the pivot axial diameter to the latch mount feature.

