


# TABLE OF CONTENTS



# CONTENTS

## MTPM DC MOTORS USER MANUAL

WARNINGS.....	W-1
~ WARNING ~.....	W-1
TRADEMARKS.....	W-1
~ AVERTISSEMENT ~.....	W-2
MARQUES DE COMMERCE.....	W-2
USER MANUAL REVISION HISTORY.....	H-1
MTPM DC MOTORS USER MANUAL TABLE OF CONTENTS.....	TOC-1
CHAPTER 1: GETTING STARTED.....	1-1
MANUAL OVERVIEW.....	1-2
OVERVIEW OF THIS PUBLICATION.....	1-2
WHO SHOULD READ THIS MANUAL.....	1-2
TECHNICAL SUPPORT.....	1-2
SPECIAL SYMBOLS.....	1-2
RECEIVING AND INSPECTION.....	1-2
UNPACKING.....	1-2
AVAILABLE MODELS.....	1-3
IRONHORSE MOTORS PART NUMBER INFORMATION.....	1-3
PERMANENT MAGNET DC MOTORS FEATURES AND SPECIFICATIONS.....	1-3
RESHIPPING.....	1-6
LONG TERM STORAGE.....	1-6
WARRANTY.....	1-6
CHAPTER 2: MOUNTING AND INITIAL STARTUP.....	2-1
SAFETY INFORMATION.....	2-2
DANGER!.....	2-2
WIRING NOTES: PLEASE READ PRIOR TO INSTALLATION.....	2-2
APPLICABLE CODES.....	2-2
MOTOR DIMENSIONS.....	2-3
TERMINAL DIAGRAM AND WIRING.....	2-5
MOTOR MOUNTING.....	2-5
STABLE SLIDE BASES.....	2-5
PROPER INSTALLATION CONDITIONS.....	2-6
COUPLING ALIGNMENT.....	2-6
MOTOR NAMEPLATE AND STARTER INFORMATION.....	2-7
TYPICAL IRONHORSE MOTOR NAMEPLATE.....	2-7
MOTOR CONTROL INFORMATION.....	2-7

INSPECTION BEFORE STARTUP.....	2-7
INITIAL STARTUP INSPECTION.....	2-7
<b>CHAPTER 3: MAINTENANCE AND TROUBLESHOOTING.....</b>	<b>3-1</b>
ROUTINE MAINTENANCE.....	3-2
BEARING SIZE INFORMATION.....	3-2
REPLACING BRUSHES.....	3-3
TROUBLESHOOTING.....	3-4
<b>CHAPTER 4: ACCESSORIES.....</b>	<b>4-1</b>
STABLE SLIDE BASES.....	4-2
SLIDE BASE SELECTION.....	4-2
SLIDE BASE DIMENSIONS.....	4-2
REPLACEMENT ACCESSORIES.....	4-3
<b>CHAPTER 5: REFERENCE.....</b>	<b>5-1</b>
INTRODUCTION TO PERMANENT MAGNET DC MOTORS.....	5-2
INTRODUCTION.....	5-2
FORM FACTOR.....	5-2
ENCLOSURE AND ELECTRICAL INSULATION SYSTEMS.....	5-3
PERMANENT MAGNETS.....	5-3
BRUSHES.....	5-4
POWER SUPPLY.....	5-5
DC MOTOR TYPES.....	5-6
PERMANENT MAGNET MOTORS.....	5-6
CONTROLLING SPEED.....	5-6
LOAD CONSIDERATIONS.....	5-6
HIGH TEMPERATURE CONSIDERATIONS.....	5-7
CONTAMINATION CONSIDERATIONS.....	5-7
VIBRATION CONSIDERATIONS.....	5-7
ALTITUDE CONSIDERATIONS.....	5-7
AMBIENT TEMPERATURE.....	5-8
TYPICAL PERFORMANCE DATA FOR SMALL-FRAME PMDC MOTORS.....	5-9
12/24VDC SMALL-FRAME PMDC MOTORS.....	5-9
90VDC SMALL-FRAME PMDC MOTORS.....	5-14
180VDC SMALL-FRAME PMDC MOTORS.....	5-16
JUNCTION BOX DIMENSIONS FOR 56C-FRAME MOTORS.....	5-18
SHIPPING CRATE DIMENSIONS FOR 56C-FRAME MOTORS.....	5-18
DECIBEL LEVELS FOR 56C-FRAME MOTORS.....	5-18
PERFORMANCE CURVES FOR 56C-FRAME MOTORS.....	5-19
MTPM-P33-1L18.....	5-19
MTPM-P50-1L18.....	5-20
MTPM-P75-1L18.....	5-21
MTPM-001-1L18.....	5-22
MTPM-1P5-1L18.....	5-23
MTPM-P33-1M18.....	5-24
MTPM-P50-1M18.....	5-25
MTPM-P75-1M18.....	5-26

---

<i>MTPM-001-1M18</i> .....	5-27
<i>MTPM-1P5-1M18</i> .....	5-28
<i>MTPM-002-1M18</i> .....	5-29

