


Table of Contents



Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Chapters	1-3
Conventions Used	1-3
Key Topics for Each Chapter	1-3
OP-406 Overview	1-4
Plan your System	1-4
General Panel Information	1-4
Indicator Lamps and Pushbuttons	1-4
Back-Panel Layout	1-5
Serial Communications Port	1-5
Power Receptacle	1-5
Frequently Asked Questions	1-6

Chapter 2: Installation and Specifications

Labeling the Lamps and Pushbuttons	2-2
Labeling the Lamps and Pushbuttons	2-2
Creating the Labels	2-2
Creating Labels Using OP-WINEDIT	2-2
Templates for Manually Creating Labels	2-4
Dimensions for Mounting	2-5
Panel Specifications	2-6
Physical Specifications	2-6
Environmental Specifications	2-6
Operating Specifications	2-6
Power Supply Connections	2-7
Power Supply Connections	2-8
Connecting the Configuration Cable	2-8
Configuration Cable	2-8
Selecting a Communications Cable	2-9
Communications Cable Details	2-10
OP400 Series Communications Cables	2-10

Chapter 3: Understanding the Features

Learning the Features	3-2
Indicator Lamp and Pushbutton Operations	3-3
Reading Pushbutton Status	3-3
Turning on a Lamp	3-3
Flashing a Lamp	3-3
Turning on the Inset LED	3-3



PLC Registers **3-4**
 PLC Register Overview 3-4
 PLC Register Map 3-4
 Force Commands 3-4
DirectLOGIC User Memory Overview **3-6**

Chapter 4: Configuring Your Operator Panel

Preparing for Configuration **4-2**
 OP-WINEDIT Software 4-2
 More about OP-WINEDIT 4-2
 HELP Screens 4-2
 Computer System Requirements 4-3
How to Configure Your Panel **4-3**

Chapter 5: Programming Examples

Examples Using PLCDirect PLCs **5-2**
 Register Usage 5-2
Examples Using DL05, DL105, DL205, D3-350 and DL405 **5-3**
 Turning on a Lamp 5-3
 Flashing a Lamp 5-4
 Using a Button 5-4
 Lighting an Inset LED 5-5
 Flashing an Inset LED 5-5
Forcing Button Status **5-6**
 Force Button Status 5-6
 Force Button(s) On 5-6
 Force Button(s) Off 5-6
Example Using D3-340 **5-7**
 Register Usage 5-7
Examples Using Allen-Bradley SLC 5/03, 5/04 and Micrologix PLCs **5-8**
 Interfacing to A-B Memory 5-8
 Turning on a Lamp 5-8
 Flashing a Lamp 5-9
 Using a Button 5-9
 Lighting an Inset LED 5-10
 Flashing an Inset LED 5-10
Forcing Button Status **5-11**
 Force Button Status 5-11
 Force Button(s) On 5-11
 Force Button(s) Off 5-11
Troubleshooting the OP-406 Panel **5-12**

Index